

# **Beeches, Booths & Barr (3Bs) Birmingham**

SuDS Guidelines Draft

## Quality information

Document name	Ref	Prepared for	Prepared by	Date	Reviewed by
Beeches, Booths & Barr (3Bs) Report	Draft	3Bs Neighbourhood Planning Forum	Michael Henderson	08-02-2019	Ben Castell

## Limitations

AECOM Infrastructure & Environment UK Limited ("AECOM") has prepared this Report for the sole use of 3Bs Neighbourhood Planning Forum ("The Client") in accordance with the Agreement under which our services were performed. No other warranty, expressed or implied, is made as to the professional advice included in this Report or any other services provided by AECOM.

Where the conclusions and recommendations contained in this Report are based upon information provided by others it is upon the assumption that all relevant information has been provided by those parties from whom it has been requested and that such information is accurate. Information obtained by AECOM has not been independently verified by AECOM, unless otherwise stated in the Report.

The methodology adopted and the sources of information used by AECOM in providing its services are outlined in this Report. The work described in this Report was undertaken in the period of November 2018 to January 2019, although the evidence base goes wider, and is based on the conditions encountered and the information available during the said period of time. The scope of this Report and the services are accordingly factually limited by these circumstances.

Where assessments of works or costs identified in this Report are made, such assessments are based upon the information available at the time and where appropriate are subject to further investigations or information which may become available.

AECOM disclaim any undertaking or obligation to advise any person of any change in any matter affecting the Report, which may come or be brought to AECOM's attention after the date of the Report.

Certain statements made in the Report that are not historical facts may constitute estimates, projections or other forward-looking statements and even though they are based on reasonable assumptions as of the date of the Report, such forward-looking statements by their nature involve risks and uncertainties that could cause actual results to differ materially from the results predicted. AECOM specifically does not guarantee or warrant any estimate or projections contained in this Report.

Where field investigations are carried out, these have been restricted to a level of detail required to meet the stated objectives of the services. The results of any measurements taken may vary spatially or with time and further confirmatory measurements should be made after any significant delay in issuing this Report.

## Copyright

© This Report is the copyright of AECOM Infrastructure & Environment UK Limited. Any unauthorised reproduction or usage by any person other than the addressee is strictly prohibited.

All maps reproduced courtesy of Emapsite © Crown copyright and database rights 2019 Ordnance Survey 0100031673.

## Contents

01 Background and Introduction.....	5
02 What are SuDS .....	9
03 Existing Planning Policy .....	13
04 Policy Recommendations .....	15
05 SuDS Design Guidelines .....	17
06 Calculating Attenuation Volume .....	25



# **Background and Introduction**

**1.0**

## 1.0 Problem Flooding Around Perry Beeches

When rain falls on an impermeable surface, it runs off as surface water. Usually, this water flows into drainage gullies and into the combined foul and storm water sewers. If the rainfall is particularly heavy, as it was in 2016, this surface water can flow towards the drainage gullies at such a rate they become overwhelmed and water backs up as surface water flooding. Sometimes the volume of water entering the combined sewers is so high that the sewers overflow posing further health risks.

This situation is further exacerbated in the Perry Beeches area due to the local topography which creates two relatively steep sided valleys to the northwest and west (see Figures 1 and 2). This helps surface water to flow quickly down towards the largely culverted Perry Brook and the M6 embankment where it gets trapped; backing up and further increasing flood risk along the historic route of Perry Brook and Thornbridge Avenue. Without the ability to drain, this water will continue to flow towards Haddon Road where the sewer infrastructure can become overwhelmed and overflow<sup>1</sup>.

Water flowing over impermeable surfaces, such as the roads in Perry Beeches, is likely to pick up diffuse urban pollution, such as heavy metals from car exhausts. If this is able to pool and flood, this pollution becomes concentrated and can present widespread health and environmental risks.






Figure 1.1 Flooded underpass in Perry Barr (source Birmingham Mail)

<sup>1</sup> June 2016 Flooding: Flood and Water Management Act,



- - - Neighbourhood Area Boundary
- Motorways
- Waterways
- High Risk
- Medium Risk
- Low Risk
- Very Low Risk

Figure 1.2 Flood Risk In Perry Beeches



- - - Neighbourhood Area Boundary
- Motorways
- Waterways
- Watercourse
- - - Culvert
- ➔ Flow Route

Figure 1.3 Surface Water Flows in Perry Beeches



**What Are SuDS?**

**2.0**

## 2.0 SuDS Definition

The term SuDS stands for Sustainable Drainage Systems. It covers a range of approaches to managing surface water in a more sustainable way to reduce flood risk and improve water quality whilst improving amenity benefits. There are a number of overarching principles for SuDS:



Manage surface water as close to where it originates as possible



Reduce runoff rates by facilitating infiltration into the ground or by providing attenuation that stores water to help slow its flow down so it does not overwhelm water courses or the sewer network.



Improve water quality by filtering pollutants to help avoid environmental contamination.



Form a 'SuDS train' of two or three different surface water management approaches.



Integrate into develop and improve amenity through early consideration in the development process and good design practices.



SuDS are often as important in areas that are not directly in an area of flood risk themselves, as they can help reduce downstream flood risk by storing water upstream.



Some of the most effective SuDS are vegetated, using natural processes to slow and clean the water whilst increasing the biodiversity value of the area.




Best practice SuDS schemes link the water cycle to also help make the most efficient use of water resources by reusing surface water.




Figure 2.1 Roadside rain garden intervention

**Natural Water Balance**



**Urban Water Balance**



**SuDS Water Balance**




Figure 2.2 Diagrams Illustrating alternating water cycles



**Existing Planning Policy**

**3.0**

---

## 3.0 Existing Planning Policy

---

The National Planning Policy Framework (NPPF) (2018) requires local planning authorities to ensure that development does not increase flood risk, both on site and elsewhere. It highlights that any increase in flood risk should be mitigated, potentially by incorporating SuDS, unless there is clear evidence that this would be inappropriate.

Birmingham City Council's Development Plan 2031 sets out planning policy across the city. It includes policy TP6 on the management of flood risk and water resources sets out that:

*'To minimise flood risk, improve water quality and enhance biodiversity and amenity all development proposals will be required to manage surface water through Sustainable Drainage Systems (SuDS).'*

Development covers a range of activities that affect the use of land and buildings. Permitted Development Rights, however, enable some works to be undertaken without the need for planning permission. This includes extending residential properties so long as the development does not exceed 50% of the total area of land around the original house (including previous extensions).

In 2008 Permitted Development Rights enabling the resurfacing of front gardens were tightened to help reduce surface water flooding risks. Planning permission is not required if a new or replacement driveway of any size uses permeable (or porous) surfacing, such as gravel, permeable concrete block paving or porous asphalt, or if the rainwater is directed to a lawn or border to drain naturally. Planning permission is however required if the surface to be covered is more than five square metres of traditional, impermeable driveways that do not provide for the water to run to a permeable area<sup>1</sup>. This is particularly important for the Perry Beeches area which has seen a large number of front drives resurfaced.

Birmingham's Sustainable Drainage: Guide to Design, Adoption and Maintenance highlights that SuDS should not be restricted to just major developments, *but prioritised on any development (major or minor) where there is benefit to reducing flood risk*. Furthermore, the Guide emphasises that new development is likely to be a relative small proportion of urban areas and that retrofitting SuDS is actively encouraged where it can be promoted as a means of mitigating flood risk in existing developments.

---

<sup>1</sup> 2. Part 1, Class of the Town and Conrty Planning (general Permitted Development) (England) Order 2015 sets out the permitted development rights in relation to paving

# Policy Recommendations

# 4.0

---

## 4.0 Neighbourhood Plan Policy Recommendations

---

Neighbourhood Plans have to support the strategic plans set out the Local Development Plan and in accordance with the NPPF. Both the NPPF and Birmingham's Local Development Plan require the use of SuDS to mitigate the additional surface water flood risks associated with development. Enforcement of these policies across the Perry Beeches area has been limited (particularly in relation to front garden conversion to drives) and the consequential impact of permitted development contributes to increased flood risk across the area.

Reducing surface water flow rates across the Perry Beeches area will not only reduce immediate surface water risks, but also lower the risk of downstream sewer flooding and fluvial flooding and in turn reducing the scale and cost of strategic flood risk reduction works. As such, local, small scale SuDS will play a role in managing surface water. The Neighbourhood Plan therefore has a role to play by reinforcing and enhancing surface water management policies. Central to this is the need to enforce policies associated with new built development and conversion of front gardens that promote infiltration or the slow release of surface water to a water course or drainage network.

The following policy is recommended alongside the design guidance:

- All development, including the conversion of front gardens for parking, should demonstrate the SuDS Design Guidelines have been used mitigate for run-off generated from an increase in impermeable area covering the site.

# SuDS Design Guidelines

# 5.0

## 5.0 SuDS Design Guidelines

SuDS work by reducing the amount and rate at which surface water reaches the combined sewer system. Perhaps the most sustainable option is collecting this water for reuse, for example in a water butt or rainwater harvesting system, as this has the added benefit of reducing pressure on important water sources.

Where reuse is not possible there are two alternative approaches from SuDS:

- Infiltration, which allows water to percolate into the ground and eventually restore groundwater; and
- Attenuation and controlled release, which holds back the water and slowly releases it into the sewer network. Although the overall volume entering the sewer system is the same, the peak flow is reduced. This reduces the risk of sewers overflowing. Attenuation and controlled release options are suitable when we either cannot infiltrate (for example where the water table is high or soils are clay) or where infiltration could be polluting (such as on contaminated sites).

The map shown in figure 5.1 shows where in the 3Bs area that infiltration SuDS can be used and where there use is limited due to the ground conditions. This mapping should be used as a guide and drainage test should be done on site to understand infiltration rate potential.




Figure 5.1 Map showing 3Bs areas of infiltration SuDS

## 5.1 SuDS Definitions



Permeable paving – This is durable paving that allows for surface water to percolate through into underlying substrate sub base. Spaces within the substrate enable the water to be held before it infiltrates or is released. Permeable paving can also be use with create systems that can hold even more water. Permeable paving can also help to remove solids and pollutants from surface water.



Soak way / rain garden – These planted spaces are designed to enable water to infiltrate into the ground. Cutting of downpipes and enabling roof water to flow into raingardens can significantly reduce the runoff into the sewer system. The UK Rain Garden Design Guidelines provides more detailed guidance on their virility and suggests planting to help improve water quality as well as attract biodiversity. <https://raingardens.info/wp-content/uploads/2012/07/UKRainGarden-Guide.pdf>



Storage and slow release – Simple storage solutions, such as water butts, can help provide significant attenuation. To be able to continue to be able to provide benefit, there has to be some headroom within the storage solution. If water is not reused, a slow release valve allows water from the storage to trickle out recreating capacity for future rainfall events. Some digital technologies are now available that predict rainfall events enabling stored water to be realised when the sewer has greatest capacity to accept it.




Green roofs – Vegetated roofs help to slow the flow of water to down pipes. As the substrate layer provides attenuation space, the thicker the substrate layer, the higher the storage volume on the green roof. In heavy rainfall events these can get overwhelmed but can provide around 5-10% of attenuation needs.




## 5.2 Current Design Issues


There are many different approaches to sustainable drainage. This section illustrates how SuDS might be integrated into typical front and back gardens within the neighbourhood plan area. It also provides more detailed illustration as to how SuDS should be constructed to ensure that they function properly.




**Permavoid Units**




**Storm water planter**




**Rain Garden**




**Permeable Paving**



**Water Butt**




**Depaving**







### Green/ Blue Roof




### Storm water planter




### Rain Garden




### Permeable Paving



### Water Butt



### Soakaway





# Calculating Attenuation Volume

06

# 6.0 Surface water storage estimation tool-Guidance

Different surfaces allow for differing levels of infiltration. As such, and depending on the design of the development, it may be required to attenuate some of the surface water generated on site. The following section provides guidance on using the UK SuDS Tool to calculate the required attenuation volume to reduce runoff rates to an acceptable level using different types of SuDS.

The following tables represent a step by step guidance . You can access the UK SuDS Tool here: <http://www.uksubs.com/drainage-calculation-tools/surface-water-storage>

### Site Address

Enter the postcode where your site is located and click the search button. You can click on the map to the site coordinates and related hydrological characteristics. Alternatively you can directly zoom in the map and click on the exact location



Site latitude

Site longitude

Auto updates once site is selected

### Site Details

Site name

Site location

For personal reference, no impact on calculations

### Site Characteristics

Total site area (ha)	<input type="text" value="1"/>	Update with building /extension footprint
Significant public open space (ha)	<input type="text" value="0"/>	Remains 0 unless on public land
Area positively drained (ha)	<input type="text" value="0"/>	Auto- updates
Impermeable area (ha)	<input type="text" value="2"/>	Same value as 1 unless permeable surfaces are proposed
Drained area that is impermeable (%)	<input type="text" value="0"/>	Auto- updates
Impervious area drained via infiltration (ha)	<input type="text" value="3"/>	Same value as 1 unless infiltration is proposed
Return period for infiltration system design (years)	<input type="text" value="-"/>	Leave default if no infiltration is proposed. Use 100 otherwise.
Impervious area drained to rainwater harvesting systems (ha)	<input type="text" value="0"/>	Remains 0 unless rainwater harvesting is proposed
Return period for rainwater harvesting system design (years)	<input type="text" value="-"/>	Leave default if no rainwater harvesting is proposed (100 if not)
Compliance factor for rainwater harvesting system design (%)	<input type="text" value="-"/>	Leave default
Net site area for storage volume design (ha)	<input type="text" value="0"/>	Auto- updates
Net impermeable area for storage volume design (ha)	<input type="text" value="0"/>	Auto- updates
Previous area contribution (%)	<input type="text" value="30"/>	leave default

### Hydrological Characteristics

This section auto-updates. Leave default values.

These data come from the click on the map. The values on the left can be edited

	My values	Map values
SARR (mm)	<input type="text" value="-"/>	<input type="text" value="-"/>
M5-60 rainfall depth (mm)	<input type="text" value="-"/>	<input type="text" value="-"/>
'r' ratio M5 / M5-2day	<input type="text" value="-"/>	<input type="text" value="-"/>
FEH/FSR conversion factor	<input type="text" value="-"/>	<input type="text" value="-"/>
Hydrological region	<input type="text" value="-"/>	<input type="text" value="-"/>

Figure 6.1 Guidance produced by AECOM, January 2019, based on UK SuDS- Surface Water Storage Volume Estimation Tool produced by HR Wallingford

### Design Criteria

Specify volume control approach This section auto-updates. Leave default values.

Climate change allowance factor

Urban creep allowance factor

Interception rainfall depth (mm)

Minimum flow rate (l/s)  Only update if known greenfield runoff rate or agreed discharge is known.

### Selected method to calculate surface water storage requirements

IH124 method

IH124 specifically addresses the runoff from the small catchments (Insitute of Hydrology,1994). Although shown to be slightly less accurate than more recent FEH based methods, it is still considered to be an acceptable approach for assessing greenfield runoff rates.

Input fields for the IH124 method

Enter criteria needed to calculate surface water storage requirments with the IH124 method.

#### 1. Growth curve factors

This section auto-updates. Leave default values.

	My values	Map values
Growth curve factor 1 year	<input type="text"/>	<input type="text"/>
Growth curve factor 10 years	<input type="text"/>	<input type="text"/>
Growth curve factor 30 years	<input type="text"/>	<input type="text"/>
Growth curve factor 100 years	<input type="text"/>	<input type="text"/>

### 2. Derivation of Qbar

Auto-updates. Leave default values.

	My values	Map values
Specify how Qbar should be delivered		
Specify how SPR should be delivered		
Specify SOIL type	<input type="text"/>	<input type="text"/>
SPR	<input type="text"/>	<input type="text"/>

### 3. Rainfall Input

Auto-updates. Leave default values.

Rainfall 100 yrs 6hrs (mm)	<input type="text"/>	<input type="text"/>
Rainfall 100 yrs 12hrs (mm)	<input type="text"/>	<input type="text"/>

### Results using the IH124 method

Estimated site discharges This section auto-updates.

	My values	Map values
Qbar (l/s)	<input type="text"/>	<input type="text"/>
1 in 1 year (l/s)	<input type="text"/>	<input type="text"/>
1 in 30 year (l/s)	<input type="text"/>	<input type="text"/>
1 in 100 years (l/s)	<input type="text"/>	<input type="text"/>

Site discharge rates for the proposed impermeable area increase if no limitations are applied. Discharge rate should be agreed with the local sewer company.

### Estimated storage volumes

Interception storage (m <sup>3</sup> )	<input type="text"/>	<input type="text"/>
Attenuation storage (m <sup>3</sup> )	<input type="text" value="Required"/>	<input type="text"/>
Long term storage (m <sup>3</sup> )	<input type="text"/>	<input type="text"/>
Treatment storage (m <sup>3</sup> )	<input type="text"/>	<input type="text"/>
Total storage (m <sup>3</sup> )	<input type="text"/>	<input type="text"/>

Attenuation storage required for proposed impermeable area increase. This is a guidance tool only.

Description of this model run

Figure 6.2 Guidance produced by AECOM, January 2019, based on UK SuDS- Surface Water Storage Volume Estimation Tool produced by HR Wallingford